

INSTRUCTION MANUAL

THE DESTROYER FROM JAIL

■ HORIZONTAL CONVERSION GAME.

1 OR 2 PLAYER CAN ENJOY WITH THIS GAME.

SECOND PLAYER CAN JOIN GAME AT ANY TIME

5 THRILLING AND ACTIVE STAGES.






PhilKo


PhilKo Corporation

ADD: # 193, NAKWON-DONG,
JONGRO-GU, SEOUL, KOREA
TELEX: PHILKO K29617
FACSIMILE: (02) 274-2846
TEL: (02) 741-0101 / 744-1128

OPTION ITEM

FEATURE	NAME	DESCRIPTION
	MAGAZINE	EXTRA BULLETS
	BOMB	ROCKET BOMB
30000	BONUS	BONUS POINTS
	WATCH	EXTEND TIMES
1-UP	1 - UP	ONE MORE PLAYER
POW	POWER	EXTEND POWER


CONTROL PANEL LAYOUT ■



PIN ASSIGNMENT

SOLDER SIDE			COMPONENT SIDE	
GND	A	1	GND	
GND	B	2	GND	
+5V	C	3	+5V	
+5V	D	4	+5V	
	E	5		
+12V	F	6	+12V	
	G	7		
	H	8		
Coin Counter 2	I	9	Coin Counter 1	
SPEAKER (-)	J	10	SPEAKER (+)	
	K	11		
GREEN	L	12	RED	
SYNC	M	13	BLUE	
	N	14	VIDEO GND	
	O	15		
COIN 2	P	16	COIN 1	
2P START	Q	17	1P START	
2P UP	R	18	1P UP	
2P DOWN	S	19	1P DOWN	
2P LEFT	T	20	1P LEFT	
2P RIGHT	U	21	1P RIGHT	
2P SHOOT	V	22	1P SHOOT	
2P JUMP	W	23	1P JUMP	
2P ROCKET GUN	X	24	1P ROCKET GUN	
	Y	25		
	Z	26		
GND	a	27	GND	
GND	b	28	GND	

DIP SW POSITION



DIP SW 1

Coin / Credit option switch setting

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
COIN	1coin 1credit	off	off	off	off				
	1coin 2credit	on	off	off	off				
	1coin 3credit	off	on	off	off				
	1coin 4credit	on	on	off	off				
	1coin 5credit	off	off	on	off				
	1coin 6credit	on	off	on	off				
	1coin 7credit	off	on	on	off				
	1coin 8credit	on	on	on	off				
	2coin 1credit	off	off	off	on				
	3coin 1credit	on	off	off	on				
	4coin 1credit	off	on	off	on				
	5coin 1credit	on	on	off	on				
	6coin 1credit	off	off	on	on				
	7coin 1credit	on	off	on	on				
	8coin 1credit	off	on	on	on				
	free play	on	on	on	on				
NUMBER OF PLAYER	1credit - 1play					off	off	off	
	1credit - 2play					on	off	off	
	1credit - 3play					off	on	off	
	1credit - 4play					on	on	off	
	1credit - 5play					off	off	on	
	1credit - 6play					on	off	on	
	1credit - 7play					off	on	on	
	1credit - 8play					on	on	on	
MODE	game mode								off
	test mode								on

DIP SW 2

Option switch setting

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
GAME DIFFICULTY	easy	off	off						
	normal	on	off						
	hard	off	on						
	hardest	on	on						
MUSIC in DEMO SCREEN FLIP	off			off					
	on			on					
	normal				off				
	reverse				on				